

**maxon motor**

maxon motor control

EPOS Positioning Controller

IEC 1131 Beckhoff Library

Edition December 2009

***EPOS***

Positioning Controller

Documentation

**IEC 1131 Beckhoff Library**

## 1 Table of contents

1	Table of contents .....	2
2	Table of figures .....	3
3	Introduction .....	4
4	Third party products .....	4
5	How to use this guide .....	5
6	Virtual Command Set .....	6
6.1	Configuration .....	6
6.1.1	Get Current Regulator Gain .....	6
6.1.2	Get Encoder Parameter .....	7
6.1.3	Get Motor Parameter .....	8
6.1.4	Get Position Regulator Gain .....	9
6.1.5	Get Velocity Regulator Gain .....	10
6.1.6	Set Current Regulator Gain .....	11
6.1.7	Set Encoder Parameter .....	12
6.1.8	Set Motor Parameter .....	13
6.1.9	Set Position Regulator Gain .....	14
6.1.10	Set Velocity Regulator Gain .....	15
6.2	Current Mode .....	16
6.2.1	Get Current Must .....	16
6.2.2	Set Current Must .....	17
6.3	Homing Mode .....	18
6.3.1	Find Home .....	18
6.3.2	Get Homing Parameter .....	19
6.3.3	Set Homing Parameter .....	20
6.3.4	Stop Homing .....	21
6.4	Inputs Outputs .....	22
6.4.1	Get All Digital Inputs .....	22
6.4.2	Get All Digital Outputs .....	23
6.4.3	Get Analog Input .....	24
6.4.4	Set All Digital Outputs .....	25
6.5	Motion Info .....	26
6.5.1	Get Current Is .....	26
6.5.2	Get Movement State .....	27
6.5.3	Get Position Is .....	28
6.5.4	Get Velocity Is .....	29
6.6	Position Mode .....	30
6.6.1	Get Position Must .....	30
6.6.2	Set Position Must .....	31
6.7	Profile Position Mode .....	32
6.7.1	Get Position Profile .....	32
6.7.2	Get Target Position .....	33
6.7.3	Halt Position Movement .....	34
6.7.4	Move To Position .....	35
6.7.5	Set Position Profile .....	36
6.8	Profile Velocity Mode .....	37
6.8.1	Get Target Velocity .....	37
6.8.2	Get Velocity Profile .....	38
6.8.3	Halt Velocity Movement .....	39
6.8.4	Move With Velocity .....	40
6.8.5	Set Velocity Profile .....	41
6.9	State Machine .....	42
6.9.1	Clear Fault .....	42
6.9.2	Get Disable State .....	43
6.9.3	Get Enable State .....	44
6.9.4	Get Fault State .....	45
6.9.5	Get Operation Mode .....	46
6.9.6	Get Quick Stop State .....	47
6.9.7	Set Disable State .....	48
6.9.8	Set Enable State .....	49
6.9.9	Set Operation Mode .....	50
6.9.10	Set Quick Stop State .....	51
6.10	Utilities .....	52
6.10.1	Get Object .....	52
6.10.2	Get Version .....	53
6.10.3	Restore .....	54

6.10.4 Set Object .....	55
6.10.5 Store .....	56
6.11 Velocity Mode .....	57
6.11.1 Get Velocity Must .....	57
6.11.2 Set Velocity Must .....	58
7 History .....	59

## 2 Table of figures

Figure 1: EPOS documentation hierarchy .....	5
Figure 2: FB_GetCurrentRegulatorGain .....	6
Figure 3: FB_GetEncoderParameter .....	7
Figure 4: FB_GetMotorParameter .....	8
Figure 5: FBGetPositionRegulatorGain .....	9
Figure 6: FB_GetVelocityRegulatorGain .....	10
Figure 7: FB_SetCurrentRegulatorGain .....	11
Figure 8: FB_SetEncoderParameter .....	12
Figure 9: FB_SetMotorParameter .....	13
Figure 10: FB_SetPositionRegulatorGain .....	14
Figure 11: FB_SetVelocityRegulatorGain .....	15
Figure 12: FB_GetCurrentMust .....	16
Figure 13: FB_SetCurrentMust .....	17
Figure 14: FB_FindHome .....	18
Figure 15: FB_GetHomingParameter .....	19
Figure 16: FB_SetHomingParameter .....	20
Figure 17: FB_StopHoming .....	21
Figure 18: FB_GetAllDigitalInputs .....	22
Figure 19: FB_GetAllDigitalOutputs .....	23
Figure 20: FB_GetAnalogInput .....	24
Figure 21: FB_SetAllDigitalOutputs .....	25
Figure 22: FB_GetCurrentIs .....	26
Figure 23: FB_GetMovementState .....	27
Figure 24: FB_GetPositionIs .....	28
Figure 25: FB_GetVelocityIs .....	29
Figure 26: FBGetPositionMust .....	30
Figure 27: FB_SetPositionMust .....	31
Figure 28: FBGetPositionProfile .....	32
Figure 29: FBGetTargetPosition .....	33
Figure 30: FB_HaltPositionMovement .....	34
Figure 31: FB_MoveToPosition .....	35
Figure 32: FB_SetPositionProfile .....	36
Figure 33: FB_GetTargetVelocity .....	37
Figure 34: FB_GetVelocityProfile .....	38
Figure 35: FB_HaltVelocityMovement .....	39
Figure 36: FB_MoveWithVelocity .....	40
Figure 37: FB_SetVelocityProfile .....	41
Figure 38: FB_ClearFault .....	42
Figure 39: FB_GetDisableState .....	43
Figure 40: FB_GetEnableState .....	44
Figure 41: FB_GetFaultState .....	45
Figure 42: FB_GetOperationMode .....	46
Figure 43: FB_GetQuickStopState .....	47
Figure 44: FB_SetDisableState .....	48
Figure 45: FB_SetEnableState .....	49
Figure 46: FB_SetOperationMode .....	50
Figure 47: FB_SetQuickStopState .....	51
Figure 48: FB_GetObject .....	52
Figure 49: FB_GetVersion .....	53
Figure 50: FB_Restore .....	54
Figure 51: FB_SetObject .....	55
Figure 52: FB_Store .....	56
Figure 53: FB_GetVelocityMust .....	57
Figure 54: FB_SetVelocityMust .....	58

### 3 Introduction

This "IEC 1131 Beckhoff Library" documentation provides the instructions for the implemented function blocks. The library is arranged in groups of function blocks.

This library should simplify the programming of the control software based on Beckhoff PLCs.

This library is intended to cover most applications in automation.

It is based on the experience of maxon motor control.

Maxon motor control certifies that to the best of their knowledge, the content of this library is correct.

BECAUSE THIS LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THIS LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THIS LIBRARY IS WITH YOU. SHOULD THIS LIBRARY PROVE DEFECTIVE OR INSUFFICIENT, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION

The latest edition of the "IEC 1131 Beckhoff Library", additional documentation and software to the EPOS positioning controller may also be found in the internet under <http://www.maxonmotor.com> category <Service>, subdirectory <Downloads>.

### 4 Third party products

#### BECKHOFF (PLC)

[www.beckhoff.de](http://www.beckhoff.de)

## 5 How to use this guide




Figure 1: EPOS documentation hierarchy

## 6 Virtual Command Set

The Virtual Command Set defines following groups:

[Configuration](#)  
[Current Mode](#)  
[Homing Mode](#)  
[Inputs Outputs](#)  
[Motion Info](#)  
[Position Mode](#)  
[Profile Position Mode](#)  
[Profile Velocity Mode](#)  
[State Machine](#)  
[Utilities](#)  
[Velocity Mode](#)

### 6.1 Configuration

This group defines all required function blocks for device configuration:

[Get Current Regulator Gain](#)  
[Get Encoder Parameter](#)  
[Get Motor Parameter](#)  
[Get Position Regulator Gain](#)  
[Get Velocity Regulator Gain](#)  
[Set Current Regulator Gain](#)  
[Set Encoder Parameter](#)  
[Set Motor Parameter](#)  
[Set Position Regulator Gain](#)  
[Set Velocity Regulator Gain](#)

#### 6.1.1 Get Current Regulator Gain




Figure 2: FB\_GetCurrentRegulatorGain

#### Description

With function block "FB\_GetCurrentRegulatorGain" it is possible to read all current regulator gains.


#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (Is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information
P	UINT	Current Regulator P-Gain <span style="color:red;">Object: 0x60F6-01</span>
I	UINT	Current Regulator I-Gain <span style="color:red;">Object: 0x60F6-02</span>

#### Related Functions

[Set Current Regulator Gain](#)**6.1.2 Get Encoder Parameter***Figure 3: FB\_GetEncoderParameter***Description**

With function block “FB\_GetEncoderParameter“ it is possible to read all encoder parameters.

**Parameters**

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

**Return Values**

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
Counts	UINT	Incremental Encoder Counts	Object: 0x2210-01
SensorType	UINT	Position Sensor Type	Object: 0x2210-02

**Related Functions**[Set Encoder Parameter](#)

### 6.1.3 Get Motor Parameter




Figure 4: FB\_GetMotorParameter

#### Description

With function block “FB\_GetMotorParameter“ it is possible to read all motor parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network Id
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
MotorType	UINT	Kind of Motor	Object: 0x6402-00
ContinuousCurrent	UINT	Maximal Continuous Current	Object: 0x6410-01
PeakCurrent	UINT	Maximal Peak Current	Object: 0x6410-02
PolePair	USINT	Number of Pole Pairs	Object: 0x6410-03
ThermalTime-Constant	UINT	Thermal Time Constant	Object: 0x6410-05

#### Related Functions

[Set Motor Parameter](#)

### 6.1.4 Get Position Regulator Gain




Figure 5: FB\_GetPositionRegulatorGain

#### Description

With function block "FB\_GetPositionRegulatorGain" it is possible to read all position regulator gains.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network Id
NodeId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
<hr/>			
P	UINT	Position Regulator P-Gain	Object: 0x60FB-01
I	UINT	Position Regulator I-Gain	Object: 0x60FB-02
D	UINT	Position Regulator D-Gain	Object: 0x60FB-03

#### Related Functions

[Set Position Regulator Gain](#)

### 6.1.5 Get Velocity Regulator Gain




Figure 6: FB\_GetVelocityRegulatorGain

#### Description

With function block “FB\_GetVelocityRegulatorGain“ it is possible to read all velocity regulator gains.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network Id
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
P	UINT	Velocity Regulator P-Gain	Object: 0x60F9-01
I	UINT	Velocity Regulator I-Gain	Object: 0x60F9-02

#### Related Functions

[Set Velocity Regulator Gain](#)

### 6.1.6 Set Current Regulator Gain




Figure 7: FB\_SetCurrentRegulatorGain

#### Description

With function block “FB\_SetCurrentRegulatorGain” it is possible to write all current regulator gains.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network Id
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing
P	UINT	Current Regulator P-Gain
I	UINT	Current Regulator I-Gain
		Object: 0x60F6-01
		Object: 0x60F6-02

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Current Regulator Gain](#)

### 6.1.7 Set Encoder Parameter




Figure 8: FB\_SetEncoderParameter

#### Description

With function block “FB\_SetEncoderParameter” it is possible to write all encoder parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network Id	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
Counts	UINT	Incremental Encoder Counts	Object: 0x2210-01
SensorType	UINT	Position Sensor Type	Object: 0x2210-02

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Encoder Parameter](#)

### 6.1.8 Set Motor Parameter




Figure 9: FB\_SetMotorParameter

#### Description

With function block "FB\_SetMotorParameter" it is possible to write all motor parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network Id	
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
MotorType	UINT	Kind of Motor	Object: 0x6402-00
ContinuousCurrent	UINT	Maximal Continuous Current	Object: 0x6410-01
PeakCurrent	UINT	Maximal Peak Current	Object: 0x6410-02
PolePair	USINT	Number of Pole Pairs	Object: 0x6410-03
ThermalTimeConstant	UINT	Thermal Time Constant	Object: 0x6410-05

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Motor Parameter](#)

### 6.1.9 Set Position Regulator Gain



Figure 10: FB\_SetPositionRegulatorGain

#### Description

With function block "FB\_SetPositionRegulatorGain" it is possible to write all position regulator gains.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodeId	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing
P	UINT	Position Regulator P-Gain <span style="color:red;">Object: 0x60FB-01</span>
I	UINT	Position Regulator I-Gain <span style="color:red;">Object: 0x60FB-02</span>
D	UINT	Position Regulator D-Gain <span style="color:red;">Object: 0x60FB-03</span>

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Position Regulator Gain](#)

### 6.1.10 Set Velocity Regulator Gain




Figure 11: FB\_GetVelocityRegulatorGain

#### Description

With function block “FB\_SetVelocityRegulatorGain” it is possible to write all velocity regulator gains.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
P	UINT	Velocity Regulator P-Gain	Object: 0x60F9-01
I	UINT	Velocity Regulator I-Gain	Object: 0x60F9-02

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Velocity Regulator Gain](#)

## 6.2 Current Mode

This group defines all required function blocks for Current Mode:

[Get Current Must](#)  
[Set Current Must](#)

### 6.2.1 Get Current Must




Figure 12: FB\_GetCurrentMust

#### Description

With function block “FB\_GetCurrentMust” it is possible to read the current mode demand value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
CurrentMust	INT	Current mode demand value	Object: 0x2030-00

#### Related Functions

[Set Current Must](#)

### 6.2.2 Set Current Must




Figure 13: FB\_SetCurrentMust

#### Description

With function block “FB\_SetCurrentMust“ it is possible to write current mode demand value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
CurrentMust	INT	Current mode demand value	Object: 0x2030-00

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Current Must](#)

## 6.3 Homing Mode

This group defines all required function blocks for Homing Mode:

[Find Home](#)  
[Get Homing Parameter](#)  
[Set Homing Parameter](#)  
[Stop Homing](#)

### 6.3.1 Find Home




Figure 14: FB\_FindHome

#### Description

With function block “FB\_FindHome“ and the parameter “HomingMethod” it is possible to find the system home. For example a home switch.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
HomingMethod	SINT	Homing Method	Object: 0x6098-00

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Set Homing Parameter](#)  
[Stop Homing](#)

### 6.3.2 Get Homing Parameter




Figure 15: FB\_GetHomingParameter

#### Description

With function block “FB\_GetHomingParameter” it is possible to read all homing parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading


#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
HomingAcceleration	UDINT	Acceleration for Homing Profile	Object: 0x609A-00
SpeedSwitch	UDINT	Speed during search for switch	Object: 0x6099-01
SpeedIndex	UDINT	Speed during search for index signal	Object: 0x6099-02
HomeOffset	DINT	Home Offset after Homing	Object: 0x607C-00
CurrentThreshold	UINT	Current Threshold for Homing Method -3 and -4	Object: 0x2080-00

#### Related Functions

[Find Home](#)  
[Stop Homing](#)  
[Set Homing Parameter](#)

### 6.3.3 Set Homing Parameter



*Figure 16: FB\_SetHomingParameter*

#### Description

With function block “FB\_SetHomingParameter” it is possible to write all homing parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Read	BOOL	A positive edge at input Read starts writing	
HomingAcceleration	UDINT	Acceleration for Homing Profile	Object: 0x609A-00
SpeedSwitch	UDINT	Speed during search for switch	Object: 0x6099-01
SpeedIndex	UDINT	Speed during search for index signal	Object: 0x6099-02
HomeOffset	DINT	Home Offset after Homing	Object: 0x607C-00
CurrentThreshold	UINT	Current Threshold for Homing Method -3 and -4	Object: 0x2080-00

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Find Home](#)  
[Stop Homing](#)  
[Get Homing Parameter](#)

### 6.3.4 Stop Homing




Figure 17: FB\_StopHoming

#### Description

“FB\_StopHoming“ interrupts homing.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Find Home](#)

[Set Homing Parameter](#)

## 6.4 Inputs Outputs

### 6.4.1 Get All Digital Inputs



Figure 18: FB\_GetAllDigitalInputs

#### Description

“FB\_GetAllDigitalInputs“ reads all digital inputs.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
Inputs	UINT	Digital Inputs	Object: 0x2071-01

#### Related Functions

[Get All Digital Outputs](#)  
[Get Analog Inputs](#)  
[Set All Digital Outputs](#)

## 6.4.2 Get All Digital Outputs



*Figure 19: FB\_GetAllDigitalOutputs*

### Description

“FB\_GetAllDigitalOutputs” reads all digital outputs.

### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
Outputs	UINT	Digital Outputs	Object: 0x2078-01

### Related Functions

[Get All Digital Inputs](#)

[Get Analog Inputs](#)

[Set All Digital Outputs](#)

### 6.4.3 Get Analog Input




Figure 20: FB\_GetAnalogInput

#### Description

“FB\_GetAnalogInput“ reads an analog input.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading
Number	UINT	Analog Input Number

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
AnalogInput	UINT	Analog Input	Object: 0x207C-01 Object: 0x207C-02

#### Related Functions

[Get All Digital Inputs](#)  
[Get All Digital Outputs](#)  
[Set All Digital Outputs](#)

### 6.4.4 Set All Digital Outputs



*Figure 21: FB\_SetAllDigitalOutputs*

#### Description

“FB\_SetAllDigitalOutputs” writes all digital outputs.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
Outputs	UINT	Digital Outputs	Object: 0x2078-01

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get All Digital Inputs](#)

[Get All Digital Outputs](#)

[Get Analog Inputs](#)

## 6.5 Motion Info

This group defines all required function blocks for motion information:

[Get Current Is](#)  
[Get Movement State](#)  
[Get Position Is](#)  
[Get Velocity Is](#)

### 6.5.1 Get Current Is




Figure 22: FB\_GetCurrentIs

#### Description

“FB\_GetCurrentIs” returns the current actual value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
CurrentIs	INT	Current actual value	Object: 0x6078-00

#### Related Functions

[Get Movement State](#)  
[Get Position Is](#)  
[Get Velocity Is](#)

### 6.5.2 Get Movement State




Figure 23: FB\_GetMovementState

#### Description

With “FB\_GetMovementState” it is possible to check, if drive has reached the target.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information
TargetReached	BOOL	the drive has reached the target

#### Related Functions

[Get Current Is](#)  
[Get Position Is](#)  
[Get Velocity Is](#)

### 6.5.3 Get Position Is




Figure 24: FB\_GetPositionIs

#### Description

“FB\_GetPositionIs” returns the position actual value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
PositionIs	DINT	Position actual value	Object: 0x6064-00

#### Related Functions

[Get Current Is](#)  
[Get Movement State](#)  
[Get Velocity Is](#)  
[Get Position Must](#)  
[Set Position Must](#)

### 6.5.4 Get Velocity ls




Figure 25: FB\_GetVelocityls

#### Description

“FB\_GetVelocityls” reads the velocity actual value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
Velocityls	DINT	Velocity actual value	Object: 0x606C-00

#### Related Functions

[Get Current ls](#)

[Get Movement State](#)

[Get Position ls](#)

## 6.6 Position Mode

This group defines all required function blocks for position mode:

[Get Position Must](#)  
[Set Position Must](#)

### 6.6.1 Get Position Must




Figure 26: FB\_GetPositionMust

#### Description

“FB\_GetPositionMust” returns the position demand value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading


#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
PositionMust	DINT	Position demand value	Object: 0x2062-00

#### Related Functions

[Get Position Is](#)  
[Set Position Must](#)

### 6.6.2 Set Position Must



*Figure 27: FB\_SetPositionMust*

#### Description

“FB\_SetPositionMust” sets the position demand value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing
PositionMust	DINT	Position demand value <span style="color:red">Object: 0x2062-00</span>

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Position Is](#)

[Get Position Must](#)

## 6.7 Profile Position Mode

This group defines all required function blocks for profile position mode:

[Get Position Profile](#)  
[Get Target Position](#)  
[Halt Position Movement](#)  
[Move To Position](#)  
[Set Position Profile](#)

### 6.7.1 Get Position Profile




Figure 28: FB\_GetPositionProfile

#### Description

“FB\_GetPositionProfile” returns the position profile mode parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
Profile-Velocity	UDINT	Position Profile Velocity	Object: 0x6081-00
Profile-Acceleration	UDINT	Position Profile Acceleration	Object: 0x6083-00
Profile-Deceleration	UDINT	Position Profile Deceleration	Object: 0x6084-00

#### Related Functions

[Get Target Position](#)  
[Halt Position Movement](#)  
[Move To Position](#)  
[Set Position Profile](#)

### 6.7.2 Get Target Position




Figure 29: FB\_GetTargetPosition

#### Description

“FB\_GetTargetPosition” returns the profile position mode target value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
TargetPosition	DINT	Target Position	Object: 0x607A-00

#### Related Functions

[Get Position Profile](#)  
[Halt Position Movement](#)  
[Move To Position](#)  
[Set Position Profile](#)

### 6.7.3 Halt Position Movement




Figure 30: FB\_HaltPositionMovement

#### Description

With function block “FB\_HaltPositionMovement” movement stops with profile deceleration.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions


[Get Position Profile](#)

[Get Target Position](#)

[Move To Position](#)

[Set Position Profile](#)

### 6.7.4 Move To Position



*Figure 31: FB\_MoveToPosition*

#### Description

With function block “FB\_MoveToPosition” device movement starts with position profile to target position.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing
Target Position	DINT	Target Position
Absolute	BOOL	TRUE starts an absolute, FALSE a relative movement

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Position Profile](#)  
[Get Target Position](#)  
[Halt Position Movement](#)  
[Set Position Profile](#)

### 6.7.5 Set Position Profile




Figure 32: FB\_SetPositionProfile

#### Description

“FB\_SetPositionProfile” sets the position profile parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
Profile-Velocity	UDINT	Position Profile Velocity	Object: 0x6081-00
Profile-Acceleration	UDINT	Position Profile Acceleration	Object: 0x6083-00
Profile-Deceleration	UDINT	Position Profile Deceleration	Object: 0x6084-00

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Position Profile](#)  
[Get Target Position](#)  
[Halt Position Movement](#)  
[Move To Position](#)

## 6.8 Profile Velocity Mode

This group defines all required function blocks for profile velocity mode:

[Get Target Velocity](#)  
[Get Velocity Profile](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)

### 6.8.1 Get Target Velocity




Figure 33: FB\_GetTargetVelocity

#### Description

“FB\_GetTargetVelocity” returns the profile velocity mode target value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
TargetVelocity	DINT	Target Velocity	Object: 0x60FF-00

#### Related Functions

[Get Velocity Profile](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)

### 6.8.2 Get Velocity Profile




Figure 34: FB\_GetVelocityProfile

#### Description

“FB\_GetVelocityProfile” returns the velocity profile parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading


#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
ProfileAcceleration	UDINT	Velocity Profile Acceleration	Object: 0x6083-00
ProfileDeceleration	UDINT	Velocity Profile Deceleration	Object: 0x6084-00

#### Related Functions

[Get Target Velocity](#)  
[Halt Velocity Movement](#)  
[Move With Velocity](#)  
[Set Velocity Profile](#)

### 6.8.3 Halt Velocity Movement



*Figure 35: FB\_HaltVelocityMovement*

#### Description

With function block “FB\_HaltVelocityMovement” movement stops with profile deceleration.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Target Velocity](#)

[Get Velocity Profile](#)

[Move With Velocity](#)

[Set Velocity Profile](#)

### 6.8.4 Move With Velocity




Figure 36: FB\_MoveWithVelocity

#### Description

With function block “FB\_MoveWithVelocity” device movement starts with velocity profile to target velocity.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
Target-Velocity	DINT	Target Velocity	Object: 0x60FF-00

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

- [Get Target Velocity](#)
- [Get Velocity Profile](#)
- [Halt Velocity Movement](#)
- [Set Velocity Profile](#)

### 6.8.5 Set Velocity Profile




Figure 37: FB\_SetVelocityProfile

#### Description

“FB\_SetVelocityProfile” sets the velocity profile parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodeId	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing
Profile-Acceleration	UDINT	Velocity Profile Acceleration
Profile-Deceleration	UDINT	Velocity Profile Deceleration

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Target Velocity](#)

[Get Velocity Profile](#)

[Halt Velocity Movement](#)

[Move With Velocity](#)

## 6.9 State Machine

For detailed information how the state machine functions refer to document “Firmware Specification”.

This group defines all required function blocks for device state machine:

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)  
[Set Operation Mode](#)

### 6.9.1 Clear Fault




Figure 38: FB\_ClearFault

#### Description

With function block “FB\_ClearFault” the device changes from fault state to disable state.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (Is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)  
[Set Operation Mode](#)

### 6.9.2 Get Disable State




Figure 39: FB\_GetDisableState

#### Description

The function block “FB\_GetDisableState” returns the device state disable (IsDisabled = TRUE).

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
IsDisabled	BOOL	Device disable state	-

#### Related Functions

[Clear Fault](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)  
[Set Operation Mode](#)

### 6.9.3 Get Enable State




Figure 40: FB\_GetEnableState

#### Description

The function block “FB\_GetEnableState” returns the device state enable (IsEnabled = TRUE).

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information
IsEnabled	BOOL	Device enable state

#### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)  
[Set Operation Mode](#)

### 6.9.4 Get Fault State




Figure 41: FB\_GetFaultState

#### Description

The function block “FB\_GetFaultState” returns the device state fault (*IsInFault* = TRUE).

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
IsInFault	BOOL	Device fault state	-

#### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Quick Stop State](#)  
[Set Operation Mode](#)

### 6.9.5 Get Operation Mode




Figure 42: FB\_GetOperationMode

#### Description

“FB\_GetOperationMode” returns the operation mode.

Value	Mode
6 (06h)	Homing Mode
3 (03h)	Profile Velocity Mode
1 (01h)	Profile Position Mode
-1 (FFh)	Position Mode
-2 (FEh)	Velocity Mode
-3 (FDh)	Current Mode
-5 (FBh)	Master Encoder Mode
-6 (FAh)	Step/Direction Mode

Table 1: Operation modes

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information
Mode	SINT	Operation Mode

#### Related Functions

[Clear Fault](#)

[Get Disable State](#)

[Get Enable State](#)

[Get Fault State](#)

[Get Quick Stop State](#)

[Set Disable State](#)

[Set Enable State](#)

[Set Quick Stop State](#)

[Set Operation Mode](#)

### 6.9.6 Get Quick Stop State




Figure 43: FB\_GetQuickStopState

#### Description

“FB\_GetQuickStopState” returns the device state quick stop (`IsQuickStoped` = TRUE).

#### Parameters

<code>ADSNetId</code>	<code>T_AmsNetId</code>	Beckhoff specific Ams Network ID
<code>NodId</code>	<code>USINT</code>	Identification ID of the addressed device (is given from hardware switches)
<code>Read</code>	<code>BOOL</code>	A positive edge at input Read starts reading

#### Return Values

<code>Done</code>	<code>BOOL</code>	True if reading is done
<code>Err</code>	<code>BOOL</code>	True if a error has occurred
<code>ErrNo</code>	<code>UDINT</code>	Error information
<code>IsQuickStoped</code>	<code>BOOL</code>	Device quick stop state

#### Related Functions

- [Clear Fault](#)
- [Get Disable State](#)
- [Get Enable State](#)
- [Get Fault State](#)
- [Get Operation Mode](#)
- [Set Disable State](#)
- [Set Enable State](#)
- [Set Quick Stop State](#)
- [Set Operation Mode](#)

### 6.9.7 Set Disable State




Figure 44: FB\_SetDisableState

#### Description

With function block “FB\_SetDisableState” changes the device to disable state.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Clear Fault](#)

[Get Disable State](#)

[Get Enable State](#)

[Get Fault State](#)

[Get Operation Mode](#)


[Get Quick Stop State](#)

[Set Enable State](#)

[Set Quick Stop State](#)

[Set Operation Mode](#)

### 6.9.8 Set Enable State



*Figure 45: FB\_SetEnableState*

#### Description

With function block “FB\_SetEnableState” the device changes to enable state.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Quick Stop State](#)  
[Set Operation Mode](#)

### 6.9.9 Set Operation Mode




Figure 46: FB\_SetOperationMode

#### Description

“FB\_SetOperationMode” sets the operation mode. Mode can have the following values:

Value	Mode
6 (06h)	Homing Mode
3 (03h)	Profile Velocity Mode
1 (01h)	Profile Position Mode
-1 (FFh)	Position Mode
-2 (FEh)	Velocity Mode
-3 (FDh)	Current Mode
-5 (FBh)	Master Encoder Mode
-6 (FAh)	Step/Direction Mode

Table 2: Operation modes

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Write starts writing
Mode	SINT	Operation Mode

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

- [Clear Fault](#)
- [Get Disable State](#)
- [Get Enable State](#)
- [Get Fault State](#)
- [Get Operation Mode](#)
- [Get Quick Stop State](#)
- [Set Disable State](#)
- [Set Enable State](#)
- [Set Quick Stop State](#)

### 6.9.10 Set Quick Stop State




Figure 47: FB\_SetQuickStopState

#### Description

With function block “FB\_SetQuickStopState” the device changes to quick stop state.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Clear Fault](#)  
[Get Disable State](#)  
[Get Enable State](#)  
[Get Fault State](#)  
[Get Operation Mode](#)  
[Get Quick Stop State](#)  
[Set Disable State](#)  
[Set Enable State](#)  
[Set Operation Mode](#)

## 6.10 Utilities

This group defines all function blocks which do not fall in the other groups:

[Get Object](#)  
[Get Version](#)  
[Restore](#)  
[Set Object](#)  
[Store](#)

### 6.10.1 Get Object




Figure 48: FB\_GetObject

#### Description

“FB\_GetObject” returns the object Data field.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading
ObjectIndex	UINT	Object Index
ObjectSubindex	USINT	Object SubIndex
Length	USINT	Object Length

#### Return Values

Done	BOOL	True if reading is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information
Data	UDINT	Object Data

#### Related Functions

[Get Version](#)  
[Restore](#)  
[Set Object](#)  
[Store](#)

### 6.10.2 Get Version




Figure 49: FB\_GetVersion

#### Description

“FB\_GetVersion” returns the Firmware Version.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading

#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
HardwareVersion	UINT	Hardware Version	Object: 0x2003-01
SoftwareVersion	UINT	Software Version	Object: 0x2003-02
ApplicationNumber	UINT	Application Number	Object: 0x2003-03
ApplicationVersion	UINT	Application Version	Object: 0x2003-04

#### Related Functions

[Get Object](#)

[Restore](#)

[Set Object](#)

[Store](#)

### 6.10.3 Restore




Figure 50: FB\_Restore

#### Description

“FB\_Restore” restores all default parameters.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Object](#)

[Get Version](#)

[Set Object](#)

[Store](#)

### 6.10.4 Set Object




Figure 51: FB\_SetObject

#### Description

“FB\_SetObject” writes to an object Data field.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID	
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)	
Write	BOOL	A positive edge at input Write starts writing	
ObjectIndex	UINT	Object Index	-
ObjectSubindex	USINT	Object SubIndex	-
Length	USINT	Object Length	-
Data	UDINT	Object Data	-

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Object](#)

[Get Version](#)

[Restore](#)

[Store](#)

### 6.10.5 Store




Figure 52: FB\_Store

#### Description

“FB\_Store” stores all parameter.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Object](#)

[Get Version](#)

[Restore](#)

[Set Object](#)

## 6.11 Velocity Mode

This group defines all required function blocks for velocity mode:

[Get Velocity Must](#)  
[Set Velocity Must](#)

### 6.11.1 Get Velocity Must




Figure 53: FB\_GetVelocityMust

#### Description

“FB\_GetVelocityMust” returns the position demand value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
Nodeld	USINT	Identification ID of the addressed device (is given from hardware switches)
Read	BOOL	A positive edge at input Read starts reading


#### Return Values

Done	BOOL	True if reading is done	
Err	BOOL	True if a error has occurred	
ErrNo	UDINT	Error information	
VelocityMust	DINT	Velocity demand value	Object: 0x206B-00

#### Related Functions

[Get Velocity Is](#)  
[Set Velocity Must](#)

### 6.11.2 Set Velocity Must



*Figure 54: FB\_SetVelocityMust*

#### Description

“FB\_SetVelocityMust” sets the velocity demand value.

#### Parameters

ADSNetId	T_AmsNetId	Beckhoff specific Ams Network ID
NodId	USINT	Identification ID of the addressed device (is given from hardware switches)
Write	BOOL	A positive edge at input Write starts writing
Velocity Must	DINT	Velocity demand value <span style="color:red">Object: 0x206B-00</span>

#### Return Values

Done	BOOL	True if writing is done
Err	BOOL	True if a error has occurred
ErrNo	UDINT	Error information

#### Related Functions

[Get Velocity Is](#)

[Get Velocity Must](#)

## 7 History

Date	Version	Documentation	Description	
17.11.2003	0.10	Edition November 2003	<ul style="list-style-type: none"> <li>• First Library Version</li> </ul>	
16.12.2003	0.20	Edition December 2003	FB_GetEncoderParameter FB_SetEncoderParameter FB_GetMotorParameter FB_SetMotorParameter FB_GetAllDigitalInputs FB_SetAllDigitalOutputs FB_SetAllDigitalOutputs FB_GetAnalogInput FB_FindHome	new Variable SensorType new Variable SensorType Changes depend on Firmware Changes depend on Firmware Bugfix
05.02.2004	1.00	Edition February 2004	FB_GetAllDigitalInputs FB_GetAllDigitalOutputs FB_GetAnalogInput FB_SetAllDigitalOutputs	new new new new
17.06.2004	1.00	Edition June 2004	correction of different spelling mistakes	
22.07.2004	1.00	Edition July 2004	Bugfixes:-FB_FindHome set Done flag at the end of function block -FB_GetOperationMode/FB_SetOperationMode type of Mode changed from USINT to SINT -FB_SetEnableState Shutdown only if Status = Switch on Disable -FB_SetObject/FBGetObject ODIdx and ODSubidx renamed with ObjectIndex and ObjectSubindex	
10.12.2009	1.00	Edition December 2009	Library dependency changed from PlcSystem.lib to TcSystem.lib	